



ABN: 23 108 039 283

45A Metrolink Circuit West, Campbellfield, Victoria, 3061

Phone: (03) 9305 4311

Fax: (03) 8456 6597

Email: sales@bella-vista.net.au

Installation Instructions

Thank you for choosing Bella Vista for your bathroom accessories. To ensure that your installation proceeds smoothly please read through the following instructions.

Important Steps to Follow:

Step 1: It is recommended that the accessory be attached to the wall in line with a stud or noggin using suitable screws.

Step 2: Make sure of the location of any electrical wiring or plumbing before drilling into walls.

Step 3: For cavity wall applications, the total tile thickness must be 10 – 16mm.

Step 4: Use the mounting plate as a template for holes. The distance between drilled holes must be accurate to ensure correct fit when accessory is installed.

Step 5: Ensure hole center are horizontal before drilling and double check measurements. Use a level to make sure everything is straight.

Step 6: To prevent drill from moving all over the place on tiled surface it is recommended that you make a template from MDF or plywood board and put it against the tile before drilling.

Installation:

Tiled / Solid Walls

1. Drill holes 6mm diameter, 40mm deep.
2. Before you drill make sure no wires, pipes, cables, or anything else is behind the location that you are drilling in.
3. Insert rounded end of wall plugs into drilled holes and tap until flush with the wall surface.
4. Insert wall plugs into the wall.
5. Fit screws through holes in mounting plate and tighten screws.
6. For shelves / towel rail: Check alignment of both mounting plates before tightening screws.
7. Fit accessory over mounting plate/s and tighten grub screw with hex key.

Untiled Cavity Wall i.e. plasterboard, acrylic or similar

Please Note: This product is not suitable for mounting directly onto plaster board or acrylic sheeting UNLESS there is a timber stud or noggin behind it to take the load.