






# INSTRUCTION



this head has a stopper at 65 degrees, do not pull down past the stopper otherwise it will break and warranty is void.